




# TWENTY-FIVE CEILING MANUAL

CONSTANT CURRENT LAMPS MUST BE INSTALLED IN SERIAL CONNECTION



TWENTY-FIVE CEILING 350 mA

